



HOW TO USE THE KEY FEATURES OF THE ALVAFORM

HOW TO USE THE DETACHABLE ARMS AND SHOULDERS

Step 1

photo below.

Put the arms on the body like the



Step 2

Align the markers (circled in orange).

Step 3

Push the arm downward slowly.



The arms should lock in smoothly and the markers aligned.



Step 1

Put the shoulder caps on the body like the photo below.

Step 2

#FORM

Align the markers (circled in orange).

Step 3

Push the shoulder cap downward slowly.

Step 4

The shoulder cap should lock in smoothly and the markers aligned.









CORRECT POSITION

When installing the arm, remeber to align the black markers.



INCORRECT POSITION







HOW TO USE THE COLLAPSIBLE SHOULDER AND THE COLLAPSIBLE HIP

The collapsible shoulder allow users to slip slim - waisted tops or dresses over the shoulders easily. The collapsible hip allow users to slip slim - waisted bottoms over the hips easily.

NORMAL POSITION





COLLAPSIBLE POSITION





HOW TO USE SOFT BELLY

The soft belly is made from soft memory foam so that tight fitting bottoms can be buttomed on. Users can safely pin into the soft belly.







HOW TO USE THE DETACHABLE POLE

Step 1

Insert the hanging pole into the AlvaForm. The pin placement needs to be aligned with the groove.



Step 2

Push the detachable pole downwards.



Step 3

Turn the pole counter-clockwise, and the pole should push slightly upwards to lock.



HOW TO REMOVE THE DETACHABLE POLE

Step 1

Push down the detachable pole and turn clockwise.



Step 2

The pole will release.



HOW TO ROTATE THE DETACHABLE POLE

Step 1

After loosening the the knob on the full form stand, the Alvaform can be rotated left or right.



Step 2

After turning the AlvaForm to the desired position, tighten the knob to lock the AlvaForm from moving.







CAUTION

Remember not to rotate the AlvaForm when the knob is tightened, as this will damage both the stand and the AlvaForm.